


**Assembly Instructions** 

# Mounting Options







### 2 Counter Stand Mounting




#### 3 Wall Arm Mounting



### 4 Direct Mounting To Wall




# Optional Add-On: Portrait To Landscape Rotation Plate




## Placing Tablet with Connector to Dock Station

1 2 3










PUSH LOCK BUTTON TO SECURE TABLET TO DOCK STATION


Removing Tablet with Connector from Dock Station

1 2 3









PULL LATCH FORWARD


GENTLY PULL UP TO RELEASE


UNLOCK LOCK USING KEY

# COMPULOCKS

### Tablet Charge PD Compatible

### Tablet Data and Charge PD Compatible










Hardware Kit Keys






PowerMove Dock Station

## PowerMove Connector SKU: PMCON01


#### **Assembly Instructions**

# COMPULOCKS


1




2 SELECT THE ORIENTATION OF THE CONNECTOR ON THE TABLET



3




4




\*CASE SOLD SEPARATELY

5 6







NOTE: TABLET AND CONNECTOR SHOULD BE AT ROOM TEMPERATURE FOR BEST RESULTS

FOR BEST PERFORMANCE ALLOW CONNECTOR TO BOND TO TABLET FOR 12 HOURS.

IN THE BOX





REMOVE COVERS TO EXPOSE



PowerMove Connector