



1



CLEAN INDICATED AREA
USING ALCOHOL WIPES


2

REMOVE STICKER COVER FROM PLATE



3

LANDSCAPE




APPLY TO BACK OF TABLET


BOND ACHIEVES FULL
STRENGTH AFTER 12 HOURS



PORTRAIT



Mounting Options



ADHESIVE STICKER SIDE


RUBBER SIDE

NOTE: DO NOT REMOVE THE STICKER COVER
UNLESS YOU ARE APPLYING IT TO A SURFACE

Freestanding

1

CONNECT MOUNTING PLATE USING
M4 X 10mm TORX FLAT HEAD
SCREWS AND T20 L-WRENCH (PROVIDED)
AND THEN PLACE
RUBBER CAPS OVER SCREWS
NOTE: MAKE SURE THE RUBBER
SIDE IS FACING DOWN




ADHESIVE STICKER SIDE
RUBBER SIDE

Counter Mounting

1


SCREW MOUNTING PLATE TO COUNTER USING
#10 X 1 1/2" PHILLIPS PAN HEAD SCREWS (PROVIDED)
NOTE: MAKE SURE THE RUBBER SIDE
IS FACING DOWN



ADHESIVE STICKER SIDE
RUBBER SIDE

2

CONNECT MOUNTING PLATE USING
M4 X 10mm TORX FLAT HEAD
SCREWS AND T20 L-WRENCH (PROVIDED)
AND THEN PLACE
RUBBER CAPS OVER SCREWS




Adhesive Mounting

1


CONNECT MOUNTING PLATE USING
M4 X 10mm TORX FLAT HEAD
SCREWS AND T20 L-WRENCH (PROVIDED)
AND THEN PLACE
RUBBER CAPS OVER SCREWS
NOTE: MAKE SURE THE
ADHESIVE STICKER
SIDE IS FACING DOWN

↑
RUBBER SIDE
ADHESIVE STICKER SIDE
↓




2

REMOVE STICKER COVER FROM MOUNTING PLATE




3



CLEAN INDICATED
COUNTER AREA
USING ALCOHOL WIPES

4




APPLY TO COUNTER
BOND ACHIEVES FULL
STRENGTH AFTER 12 HOURS



Wall Mounting


1

SCREW MOUNTING PLATE
TO WALL USING
#10 X 1 1/2" PHILLIPS PAN HEAD
SCREWS (PROVIDED).
NOTE: MAKE SURE THE RUBBER
SIDE IS FACING THE WALL




2

CONNECT MOUNTING PLATE USING
M4 X 10mm TORX FLAT HEAD
SCREWS AND T20 L-WRENCH (PROVIDED)
AND THEN PLACE
RUBBER CAPS OVER SCREWS




3

REMOVE M3 X 10mm
TORX FLAT HEAD SCREWS
AND MOUNTING HEAD
USING T10 L-WRENCH



4


ENSURE DIRECTION OF MOUNTING HEAD MATCHES
DIAGRAM (TURN 180deg) AND REINSTALL
M3 X 10mm TORX FLAT HEAD SCREWS TO SECURE
COMPONENT USING T10 L-WRENCH



Tablet Installation


1

SLIDE THE TABLET
ONTO THE STAND



2

PUSH IN THE PIN
TO LOCK TABLET



IN THE BOX




T10 L-Wrench




M4 X 10mm Torx
Flat Head Screws



Alcohol Wipes




Tablet Plate



T20 L-Wrench




Rubber Caps




#10 X 1 1/2" Phillips
Pan Head Screws



Keys



Mounting Plate



GlideTab Stand